


# Parts for Deister Head Motion Anti-Friction Bearing-Self Oiling



## Parts for Deister Head Motion Anti-Friction Bearing-Self Oiling

Part Number	Number of Pieces Per Table	Description	Part Number	Number of Pieces Per Table	Description
20-0-1	2	Yoke Bushing	AN-22	2	Bolts for Toggle Guard
AN-1-A	1	Main Stand	AN-24	1	Set Screw for Pitman
AN-2-A	1	Main Stand Cover	AN-25	2	Set Screw for Adjusting Block
AN-3	2	Bearing House	AN-26	4	Bolt & Nut for Bearing House
AN-4	1	Shaft End Housing Seal	AN-27	8	Cap Screw for Bearing Housing Seal
AN-4-Seal	1	Oil Seal	AN-29	1	Yoke Pin
AN-6	1	Closed End Housing Seal	AN-30	1	Pitman Roller Bearing
AN-7-S	1	Pitman	AN-31	2	Main Shaft Ball Bearing (No.6 Table)
AN-8-S	2	Pitman Bearing Retaining Ring	AN-31-R	2	Main Shaft Ball Bearing (No.7 Table)
AN-9-MDS	1	Main Shaft V-Belt Motor Drive	AN-32	2	Shaft End Washer
AN-10-S	2	Pitman Bearing Retaining Ring	AN-33	2	Shaft Lock Washer Bolt
AN-11	1	Adjusting Block	AN-34	1 set	Complete Set Bearing Housing Gaskets
AN-12	1	Adjusting Block Stud (Includes Washer & Nut)	AN-34-1	2 sets	Bearing Housing Gasket, Set
AN-13	1	Adjusting Block Washer	AN-34-2	2	Bearing Housing Seal Gasket
AN-14	1	Adjusting Bolt	AN-35	2	2" Pipe Plug for Main Stand
AN-15	1	Adjusting Block Pin	AN-36-M	1	1/2" Pipe Plug for Main Stand (Magnetic)
AN-16-1	1	Toggle (Iron)	AN-37	1	Fly Wheel-V-Belt Motor Drive 21" O.D.
AN-17-A	1	Yoke	AN-37-1	1	Hub for Fly Wheel
AN-18-A	1	Oil Pump Assembly	AN-41	1	Shaft Sleeve
AN-20	2	Pitman Oil Director	AN-44	1	Belt Drive Key
AN-21-B	1	Toggle Guard			